

Vibration Analysis of a Tuning Fork

Vibration analysis plays a key role in structural engineering and dynamic testing by helping researchers understand how materials and components respond to dynamic loads. In this case study, we apply MercuryRT's 3D DIC and Vibrography module to analyze the behavior of a tuning fork after an impact. The goal is to extract full-field displacement data and confirm the fork's operational mode shape.

Objective

To analyze the **vibration response** and confirm the **operational mode shape** of a tuning fork using **Digital Image Correlation (DIC)** and extract the **Operational Deflection Shapes (ODS)**.

Description of the Case Study

The test specimen was a standard **tuning fork** with a nominal operational frequency of **256 Hz**. The **field of view** was approximately 250 × 180 mm. The setup involved a **3D high-speed DIC system** consisting of:



Fig 1: Experimental setup



Test setup

- ❖ **Excitation Source:** Rubber ball hammer (tuning fork activator)
- ❖ **Cameras:** Two synchronized Chronos 2.1 high-speed cameras
- ❖ **Resolution:** 1920×1080 pixels
- ❖ **Frame Rate:** 1000 frames per second
- ❖ **Calibration Grid:** 5 mm
- ❖ **Lighting:** 2x Blue LED lights
- ❖ **Lenses:** 35 mm, 400 mm working distance
- ❖ **Software:** MercuryRT with 3D DIC and Vibrography module




Fig 2: Tested specimen

Step-by-Step Vibration Analysis with Mercury RT

The vibration analysis was conducted using the following step-by-step procedure within the Mercury RT environment:

- ❖ **Real-Time scene preparation** – the specimen was prepared by applying **2 layers of matte acrylic white paint** as the background and an acrylic matte black paint was used for the speckles. The speckle pattern has been analysed by the Focus Tool software function and evaluated by our pattern assessment. The cameras were **calibrated in real-time using a 5 mm calibration grid** which also helped set a custom coordinate system with the X axis



representing a horizontal line and the Y axis representing the vertical line. This setting of the coordinate system allows us to focus on the analysis in the X axis – the movement of the pitchforks happens in this direction.

- ❖ **Image acquisition** – Our High-Speed Capture Tool feature was used to capture **5 000 frames**. The data saved in the camera's buffer is transferred to our software via an Ethernet connection, making the frames download fast.
- ❖ **Deflection Rendering:** Upon analysis full-field displacement data, the **Vibrography tool** was used to render the frequency spectrum. This spectrum has shown two peak frequencies of the measurement. At both selected frequency, Mercury RT visualized the deflection shape of the full-field area.
- ❖ **Dynamic Animation:** To make small vibrations and/or displacements visible, Mercury RT can amplify the magnitude of the measured deflections. It can also speed up the shape's movement to make the shape visually clear to the user.

Vibrography Results

- ❖ Full-field displacement in the X axis was the primary obtained value.




Fig 3: Displacement in X [mm]

This data was used for the vibrography analysis – effectively breaking down the vibration signal using FFT into a frequency spectrum.




Fig 4: Vibration analysis – Frequency spectrum

The spectrum shows two peaks of amplitude – at a frequency of 71,7 Hz and 256,6 Hz. The deflection shapes at these frequencies look as follows:




Fig 5: ODS at 72 Hz






Fig 6: ODS at 256 Hz

The response at **256,6 Hz** is **expected** – it is the operating frequency of the tuning fork. However, the peak at **71,7 Hz** was **unexpected**, therefore we performed a further analysis to determine the cause of this.

Using our **Subset function**, the frequency spectrum was displayed for parts of the measurement at the time.




Fig 7: Frequency spectrum – first part





Fig 8: Frequency spectrum – second part

It is visible that in the first half of the measurement, the dominant frequency is the **unexpected one**. In the second half of the measurement, the **dominant frequency is the operating frequency** of the tuning fork.

Further analysis was conducted using **Point Probes** placed at both pitchforks.

The displacement was tracked for both pitchforks separately.

In the first half of the measurement, we can see that the pitchforks move in the same phase. As the impact is dampened down, the tuning fork is stabilizing at its operational frequency, and the phase of the pitchforks is opposite for the second half of the measurement.






Fig 9: InPhase displacement of the pitchforks




Fig 10: OutPhase displacement of the pitchforks

Conclusion

It has been evaluated that the **unexpected** frequency of **71,7 Hz** is a **response to the impact** where both pitchforks move in the same phase while the **operating frequency 256,6 Hz is a natural frequency** of the fork where the pitchforks move in the opposite phase.

Key Advantages of Mercury RT for Vibration Analysis

This case study demonstrates the effectiveness of **Mercury RT** for detailed vibration analysis. Key advantages of using **Mercury RT** include:

- ❖ **Non-contact, full-field measurement** of displacement and strain, eliminating the need for physical sensors on the specimen.
- ❖ **Accurate identification** of multiple vibration modes and phase relationships.
- ❖ **Detailed frequency domain analysis**, such as amplitude/phase graphs, Campbell diagrams, and animated ODS enhance engineering insight.
- ❖ **Subset analysis** to isolate specific time windows and dynamic transitions.
- ❖ **High-speed compatibility** with synchronized cameras for capturing rapid vibrations.